Recessed LED Downlight Instruction manual

PURATI

Fuoco Round Series



Please read installation manual carefully before installing this luminaire. Always switch off the mains before installation or maintenance. Keep the product far from heat sources and in a well ventilated area. This product must be installed and maintained by a qualified electrician or installer.

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



ΕN

A



Cutout: 75mm
zzzł 5-25mm



