Manual

Description Of Emergency Lighting

Compliance AS/NZS 2293.3.2018 – Emergency lighting & Exit Signs for buildings Part 2: Emergency luminaires and exit signs.

| Emergency lighting time | up to 3 hours |
|-------------------------|--|
| Light output | 300-400lm Lumen (3-4W) |
| Testing function | Automatic (Monthly, yearly) and manual |
| Battery type | Lithium |
| Battery warranty | 2 years (can be replaceable) |

The luminaire is equipped with a stand-alone emergency power supply and manual/automatic inspecting function (Monthly and Yearly).

1.Features

- a) Switching mode between MAINS and EMERGENCY power supply automatically:
- Entering Emergency Mode: MAINS < 155 +/- 10V
- Returning back to Mains Mode: MAINS > 180V
- b) Time counting:
- Start of counting: 48hours after installation
- Month: 30+/-2 days after Start of counting
- Year: 12 times of Month
- Automatic Inspection:
- Month inspection: Performing a 120s emergency status and then back to normal
- Year inspection: Performing a full discharging till the battery is fully discharged.
- Remark: Yellow indicator turns ON, shows the discharging time is less than 30 minutes. Please call a specialist for a checking.
- After the checking, press shortly the Inspection button (less than 3 seconds) to turn off the Yellow indicator.
- d) Manual Inspection function:
- Month inspection: By pressing the Inspection button for 3-5 seconds (the Green indicator is flashing a 1Hz)
- Year inspection: By pressing the Inspection button for 5-7 seconds (the Green indicator is flashing a 3Hz)
- e) Interrupting the progress of inspection: Press shortly the Inspection button (less than 3 seconds)

2.Connection:

S : for switch If switching the luminaire is not needed, you just short the L and S terminal

| T | lamp switch | es s | 1 |
|---------|-------------|------|---|
| T | | 1 | S |
| L NT | | 1 | L |
| 1/ | | 1 | N |

3.Inspection Button:

| | Press<3s | Press3-5s | Press5-7s | Press>7s |
|---------------|-----------------------------|---|---|-----------------------------------|
| Condition | Mains in normal status | Mains in normal status | Mains is in normal status | In emergency status |
| Function | Simulation of power failure | Month inspection | Year inspection | Switching back to Mains supply |
| Results | entering emergency status | The GREEN indicator flashing at 1Hz. | The GREEN indicator flashing at 3Hz | Back to Mains supply |
| After release | Back to normal status | Entering month inspection status: Performing a 120s emergency status and then back to normal status | Entering year inspection status: Performing a full discharging. | Stay in Mains supply |

[★] If the discharging time is less than 30 minutes, the yellow indicator will be on and the luminaire will be back to Mains automatically.

4.Indicators:

| Indicator | Function | Light on | Flashing | Light off |
|-----------|---|---------------------------|--|---------------|
| RED | Charging indication | charging | | Fully charged |
| GREEN | Status indication of mains and inspection | Mains status OK | 1 HZ: month inspection 3 Hz: year inspection | |
| YELLOW | Failure indication | Discharging time is short | 1Hz: Fault in charging circuit | |

